



AI powered sleep solution

Safety Instructions

Regul8



Wakefit Zense

Ai Powered Sleep Solution

REGUL8 MATTRESS TEMPERATURE CONTROLLER SAFETY INSTRUCTION MANUAL

Please read the following warnings carefully. Neglecting them could lead to severe injuries or fatalities. Like all electrical devices, improper use or failure to adhere strictly to the provided instructions may result in overheating, fire, or bodily harm. Prior to using Regul8 Mattress Temperature Controller, we strongly advise thoroughly reviewing the complete product instructions. Furthermore, any damage to Regul8 caused due to improper use may void the warranty.

- Regul8 Mattress Temperature Controller is not classified as a medical device and is not intended for diagnosing or treating medical conditions. Users should refrain from utilizing it for such purposes and seek medical advice from a qualified healthcare professional for the prevention, diagnosis, and treatment of sleep disorders and other medical concerns. The unit must be installed and operated strictly as per specifications given in the installation manual provided along with this product.
- Keep the Regul8 Console dry and away from water sources.
- Do not block the air vents of the Console
- Let there be sufficient space around the Console

- DO NOT start the Console before connecting the pipes and filling water in the Console through the provided inlet. Any damage to the Console due to starting it without water and without connecting the pipes will **VOID THE WARRANTY**.
- Check the level of water in the Console every 4 weeks and top up if required.
- Use only purified water while filling the tank of the Console.
- Never let children operate the Console
- Cleaning and user maintenance tasks should not be undertaken by children.
- Dry cleaning of any component of the product is strictly prohibited. Cleaning agents may compromise the insulation of the heating and cooling element, leading to potential hazards. Improper cleaning or laundering methods may result in sensor or cord malfunctions.
- To maintain cleanliness, it is advised to cover the Regul8 cover with a breathable mattress protector or a bed sheet.
- The heated surface of Regul8 Mattress Temperature Controller may be uncomfortable to users with sensitive skin. Users with heat sensitivity should exercise caution when using this product.
- When connecting Regul8's connector cable, water cord, or power cable, users must exercise caution to prevent trip hazards.
- Under no circumstances should the product be used with damaged cords, as this may lead to fire hazards. Users are advised against tucking, trapping, folding, crossing, or pinching cords or controls between bed slats, mattresses, springs, walls, footboards, or bed frames.

- This product should not be used on individuals who cannot comprehend the instructions provided and/or operate the mobile app.
- Regul8 Mattress Temperature Controller must not be used with infants or children.
- Children aged 8 years and above and individuals with reduced physical, sensory, or mental capabilities, or lacking experience and knowledge, may use Regul8 under supervision or after receiving proper instruction on its safe use and understanding the associated hazards. However, children should not play with the product.
- Users who are prone to entangling bed-side cords around their necks while sleeping should refrain from using the Regul8
- The heating or cooling feature of Regul8 Mattress Temperature Controller should not be used in conjunction with analgesic cream.
- Regul8 is not intended as a baby monitor and does not provide warnings for sleeping problems or potential health issues in infants.
- Regul8 is specifically designed for use with 220-240V AC electrical standards. Usage with an extension cord is not advised as it might damage the product and this may void the warranty.
- The product may experience heightened heat or cooling effects in areas where it is bunched or folded during use.
- Keep all pets, including dogs, cats, and other animals, away from Regul8, to prevent damage to the product and potential electrical hazards that may cause injury or harm.

- Combining Regul8 Mattress Temperature Controller with another temperature-regulating device is forbidden. Wrapping the cover around the body is strictly prohibited. It should be correctly installed on the mattress as directed by the setup process.
- Regul8 utilizes cords, pipes and straps that, when unassembled, pose an entanglement risk. Assembly should not be attempted in the presence of infants and children.
- Two-person assembly is recommended.
- Regul8 is exclusively designed for standard mattresses. Do not use Regul8 with futon mattresses, foldable mattresses, bunk beds, couches, or similar sleeping surfaces.
- In the event of water leakage from the Regul8 cover or Console, the device should be immediately powered off and necessary troubleshooting should be done.
- Regul8 Mattress Temperature Controller should only be used with a standard mattress size.
- No repairs should be attempted on Regul8. Unauthorized repairs may void the Limited Warranty. Replacement or repair of any part of the product by any unauthorized person or company absolves Wakefit innovation Pvt Ltd. of any liability for damages to Regul8 Mattress Temperature Controller, the bed, bedding, or any property. For any repairs, contact customer support or visit the nearest Wakefit Store.
- Don't remove the water from the bladder even while maintenance, this will **void warranty**.
- Make sure the pipe is connected to the cover before turning on the HUB. If the motors turn on without water, they will burn and this will void the warranty



Do not wash



Do not Bleach



Do not tumble dry



Do not iron



Do not dry clean



Do not puncture

Do's

- Thoroughly review the complete product instructions before using Regul8 Mattress Temperature Controller.
- Keep the Regul8 Console dry and away from water sources.
- Ensure there is sufficient space around the Console.
- Check the water level in the Console every 4 weeks and top up if required.
- Cover Regul8 Mattress Temperature Controller with a breathable mattress protector or bed sheet for cleanliness.
- Exercise caution when connecting cables to prevent trip hazards.
- Supervise children aged 8 years and above or individuals with reduced capabilities when using Regul8.
- Immediately power off the device and troubleshoot in case of water leakage.

Don'ts

- Do not block the air vents of the Regul8 Console.
- Don't let any pets or others on the Regul8.
- Do not start the Console before connecting the pipes and filling the water in the Hub.
- Do not let children operate the Console or perform cleaning and maintenance tasks.
- Avoid dry cleaning any component of the product.
- Do not use the product with damaged cords or tuck, trap, fold, or pinch cords between surfaces.
- Do not use Regul8 Mattress Temperature Controller with infants or individuals who cannot comprehend the instructions.
- Do not use the product in conjunction with analgesic cream or as a baby monitor.
- Do not use the product with another temperature-regulating device or wrap the Regul8 cover around the body.
- Do not attempt repairs on Regul8 Mattress Temperature Controller yourself, contact customer support instead.